



Continuous Authentication using Smartwatches

Siddarth Todi
Sujoy Patni

2019B2A70991P
2019B3A70575P

Introduction

- Continuous Authentication is a method of confirming a user's identity in real time.
 - Our focus is on using biometric traits or behaviors to verify the user's identity.
 - It is believed that every person has unique hemodynamics and cardiovascular system.
-
- Smartwatches have advanced a lot in the last few years.
-
- Capable of providing very accurate data on heart rate, oxygen level, no of step and much more.





Data Collection

- Collecting accurate biometric data from bio wearables is a very important step in our project.
- Initially focussed on finding ways to extract data from smartwatches using their own applications
- Borrowed smartwatches/fitness bands from friends and family to collect the necessary data.



Data Collection

- We had collected around 8-10 datasets from different smartwatches/fitness bands, ranging from different brands like Apple, Mi and Redmi smartbands.
- These data were collected using export options in the respective band's app present in mobile phones linked with watches.
- **Challenges:**
 - Many brands do not support data extraction due to security concerns.(e.g. Redmi, RealMe, etc). Also can't access sensor data directly.
 - After collecting a few datasets, we realized that the dataset varies hugely from watch to watch and brand to brand, so it is not feasible for us to analyze datasets of different types.
 - Limited number of smartwatch users on campus.
- **Possible Solution:**
 - To do sample analysis on Datasets, publicly available on internet
 - To have a smart watch, and do complete analysis using its data
 - Different brands have different sensors and hence different parameters are collected from these watches. Also the format of data collection is also different for different watches.



Data Collection

- 1) Apple Watch
Phone: Iphone
App: Health
Steps: Iphone -> Health App -> Click on Profile image on top left -> Export All Health Data -> Export -> Share via various options
The data collected is a zip file and within it .xml files are present. We then need to convert xml to csv in Excel.
- 2) MI Watch
App: MI Fit
Steps: Phone -> MI Fit App -> Profiles -> settings -> about -> exercising user rights -> export
The user needs to select the parameters and date, from which he/she wants the data to be exported.
The data collected in a zip file and a password is required to open the zip file.
- 3) Redmi Smart Band Pro
App: MI Fit
Steps:
The user needs to select the parameters and date, from which he/she wants the data to be exported.
The data collected in a zip file and a password is required to open the zip file.



Data Collection

- Next, we researched on various sensors present in different smartwatches.
- Major sensors present in bio wearables include:
 - Accelerometer: Tracks movement of your body
 - Gyroscope: Detects motion and gestures
 - Altimeter: Detects change in height and altitude
 - Temperature Sensors: Measures body temperature as well as surrounding temperature
 - Optical Heart Rate Sensor: Measures pulse rate
 - Oximetric Sensor: SpO2 and Oxygen level
 - ECG Sensor: Heart's Rhythm and electrical activity
 - And so on

Data Collection

- Selected 3-4 smartwatches that provide the maximum number of sensor capabilities and are economically feasible to work on.

sno	brand	model	spo2	24x7 body temperature	blood_pressure	heart_rate	exercise_modes	auto_sleep_tracking
1	goqii	personal care with smart vital plus	y	y	y	y	18	y
2	goqii	personal care with smart vital	y	y	y	y	18	y
3	goqii	personal care with vital 4	y	y	y	y	17	y
4	Fitbit	Charge 5	y	y	n	y		y
5	Amazfit	Bip 3	y	n	n	y	60	y
6	Espruino	Bangle.js 2	n	y	n	y		n
7	Denver	BFH-153	n	n	y	y		y
8	Denver	BFH-252	y	n	y	y		y
9	Denver	164 BlackMK2	y	y	n	y		y
10	Pebble	zen-pro	y	n	y	y		n
11	Enhance Colmi	colmi P8 Plus	y	n	y	y	8	y
12	Ambrane	Fitshot Loop	y	n	y	y		y
13	Dr Trust USA	Healthpal 1	y	y	y	y		y
14	Fire-boltt	Mercury	y	y	n	y		y
15	Hammer	Pulse Oximeter	y	y	y	y		y
16	Fire-boltt	Talk	y	n	y	y		y
17	PineTime	Open Source, hackable	n	n	n	y		n



Data Collection

- Watches selected: Goqii Smart Vital, Hammer Pulse Oximeter and OnePlus SmartBand
- **Goqii Smart Vital:** Optical Heart Sensor, SpO2, Body Temperature and Blood Pressure along with Movement Trackers
 - Challenges: App doesn't have the necessary capabilities, No developer mode
- **Hammer Pulse Oximeter:** Optical Heart Sensor, SpO2, Body Temperature and Blood Pressure along with Movement Trackers
 - Challenges: No developer mode, Doesn't store fitness data frequently
- **OnePlus SmartBand:** Optical Heart Sensor, SpO2 and Blood Pressure(different from others as its a fitness band instead of smartwatch)



Data Collection

- Shifted focus on heart rate specifically, to focus on univariate models.
- Heart Rate: the number of times the heart beats within a certain time period, usually a minute.
- Collected heart rate data from smartwatches
- Challenges:
 - As the data is collected on per minute basis, only 1 datapoint per minute is available on all the smartwatches.
 - Thus the data is not useful for continuous authentication.



Data Collection

- Photoplethysmography (PPG) is a non-invasive method for optical measurement of changes in tissue blood volume.
- The basic setup consists of a light source irradiating the tissue under examination, and a detector registering changes in light intensity due to light-tissue interaction.
- Most smartwatches use PPG method to find Heart Rate of the user
- Thus, we lose a lot of features when using heart rate instead of PPG.
- Furthermore, PPG data is as frequent as 10 data points in a single second, which can provide enough
- Thus, shifted focus to PPG data instead of Heart Rate.



Data Collection

- Extracting raw PPG data from smartwatches is a big challenge
- None of the watches provide direct access to their raw data
- Worked on creating an API for Google Fit to extract PPG data from the smartwatches.
- However, none of the watches provide access to developer options to install custom applications on them. The option is only available in high end android watches.
- Looked into creating an application on android phone and then using Google Fit to access the smartwatches for data
- Couldn't find any concrete solution for the same.




Data Collection

- Extracting raw ppg data from Smartwatches a difficult task
- Initially: aim to extract data directly from PPG sensors
- Future Work: Finding the right ppg sensors for data extraction and working with it
- SmartCare wrist-worn pulse oximeter
- Heart Pulse Monitor: Fossil Gen 5, Huawei watch 2, Galaxy watch 4 (Samsung reverted back to Wear os)
- MAXREFDES100
- HRM2511e
- MAX30100 Pulse Oximeter Heart Rate Sensor Module
- MAX30101
- Empatica E4 wristband sensor
- National Instruments device (NI cDAQ-9172)
- Maxim Integrated MAXREFDES100 device.
- SOMNOtouch NIBP
- NJL5310R, NJR Corporation, Japa

PPG Research


- Photoplethysmography (PPG) is a simple and low-cost optical technique that can be used to detect blood volume changes in the microvascular bed of tissue.
- The PPG waveform comprises a pulsatile ('AC') physiological waveform attributed to cardiac synchronous changes in the blood volume with each heartbeat, and is superimposed on a slowly varying ('DC') baseline with various lower frequency components attributed to respiration, sympathetic nervous system activity and thermoregulation.
- PPG sensors are extremely sensitive to motion, particularly in a wearable device, and have significant challenges measuring biometrics accurately during daily activities and exercise.
- PPG signal's second derivative wave contains important health-related information.



Experimentation: Heart Rate


Using one of the data which we had collected, we had done time series analysis on heart rate data. (Snapshot of a part of data attached below)

1	time	heartRate
2	0:00	107
3	0:01	97
4	0:02	84
5	0:03	80
6	0:04	90
7	0:05	93
8	0:06	94
9	0:07	82
10	0:08	119
11	0:09	91
12	0:10	94
13	0:11	80
14	0:12	92
15	0:13	93
16	0:14	84
17	0:15	77
18	0:16	76




Experimentation-Statistics

Rolling Mean(Window size=60)



Standard Deviation(Window size=60)



Challenges: Scattered discontinuous data and also step wise data(1 point/minute)



Experimentation-Statistics

Dickey-Fuller test was also conducted on this data (tests null hypothesis in univariate stationary data)

Result of Dickey-Fuller Test

Test Statistic	-4.723755
----------------	-----------

p-value	0.000076
---------	----------

#Lags Used	10.000000
------------	-----------

Number of observations Used	590.000000
-----------------------------	------------

Critical Value (1%)	-3.441482
---------------------	-----------

Critical Value (5%)	-2.866451
---------------------	-----------

Critical Value (10%)	-2.569386
----------------------	-----------

dtype: float64



Experimentation

We had taken 2 datasets of 2 hour interval each, of two different days of the same person.


1	time	heartRate
2	13:00	62
3	13:01	69
4	13:02	69
5	13:03	69
6	13:04	70
7	13:05	75
8	13:06	67
9	13:07	83
10	13:08	81
11	13:09	80
12	13:10	80
13	13:11	81
14	13:12	90
15	13:13	83
16	13:14	57
17	13:15	71
18	13:16	88

1	time	heartRate
2	13:00	77
3	13:01	90
4	13:02	82
5	13:03	91
6	13:04	81
7	13:05	77
8	13:06	76
9	13:07	92
10	13:08	93
11	13:09	80
12	13:10	90
13	13:11	83
14	13:12	102
15	13:13	102
16	13:14	87
17	13:15	78
18	13:16	90


Experimentation

Plot of the 2 datasets taken of 2 hours on different days

Data 1




Data 2




Experimentation

Comparing the plots of both the datasets




Experimentation-Statistics

Rolling Mean(Window size=10)



Standard Deviation(Window size=10)





SARIMA Model

It is a time-series forecasting model implemented on univariate stationary data.

We had implemented this model, on the 2 hour heart rate data(data-1, as shown previously)

```
Test parameters : -3.587722330343093
```

```
p-value : 0.006000135418084747
```


```
#Lags in the database : 2
```

```
Data points used : 118
```

```
Dataset is stationary
```


As the p-value is less than 0.05, the data is stationary, otherwise we had to do normalization.

SARIMA Model




Predictions

ARIMA Prediction



SARIMA Prediction(Slot size=12)



Long Short Term Memory(LSTM)

Type-1: 1 minute

Total number of points: 599

Train points: 401


Test points: 198

Look back: 1

Train Score: 3683.60 RMSE

Test Score: 3419.09 RMSE

	A	B
1	ppg	timer
2	2653440	10:48:00
3	2650560	10:48:00
4	2650767	10:48:00
5	2653281	10:48:00
6	2655284	10:48:00
7	2657600	10:48:01
8	2661857	10:48:01
9	2658077	10:48:01
10	2655382	10:48:01
11	2662347	10:48:01
12	2675967	10:48:01
13	2685597	10:48:01
14	2687903	10:48:01
15	2685354	10:48:01
16	2679560	10:48:01



Long Short Term Memory(LSTM)

Type-2: 10 seconds

Total number of points: 99

Train points: 66


Test points: 33

Look back: 1

Train Score: 3015.30 RMSE

Test Score: 2990.91 RMSE

35	2668344	10:49:03
36	2670754	10:49:03
37	2670008	10:49:03
38	2662499	10:49:04
39	2660045	10:49:04
40	2660637	10:49:04
41	2661234	10:49:04
42	2663271	10:49:04
43	2666107	10:49:04
44	2660809	10:49:04
45	2655025	10:49:04
46	2654917	10:49:04
47	2655926	10:49:04
48	2657462	10:49:05
49	2660578	10:49:05
50	2662600	10:49:05
51	2656310	10:49:05



Long Short Term Memory(LSTM)

Type-3: 5 minutes

Total number of points: 2999

Train points: 2009


Test points: 990

Look back: 1

Train Score: 65.37 RMSE

Test Score: 69.15 RMSE

1979	1857923	10:54:18
1980	1857953	10:54:18
1981	1857995	10:54:18
1982	1858053	10:54:18
1983	1858058	10:54:18
1984	1858041	10:54:18
1985	1858015	10:54:18
1986	1858053	10:54:18
1987	1858126	10:54:18
1988	1858068	10:54:19
1989	1858004	10:54:19
1990	1858112	10:54:19
1991	1858004	10:54:19
1992	1858123	10:54:19
1993	1858076	10:54:19
1994	1858052	10:54:19
1995	1858017	10:54:19
1996	1858047	10:54:19
1997	1858041	10:54:19
1998	1858036	10:54:20
1999	1857987	10:54:20
2000	1858029	10:54:20



Long Short Term Memory(LSTM)

Type-4: 40(train)-20(random) seconds (Look back: 1)

Total number of points: 599

Train points: 401


Test points: 198

Look back: 1

Train Score: 54.89 RMSE

Test Score: 154.33 RMSE

395	1858211	10:55:39
396	1858291	10:55:39
397	1858224	10:55:39
398	1858166	10:55:39
399	1858262	10:55:39
400	1858235	10:55:39
401	1858243	10:55:39
402	1858102	10:55:40
403	1858390	10:56:40
404	1858325	10:56:40
405	1858260	10:56:40
406	1858353	10:56:40
407	1858381	10:56:40
408	1858357	10:56:41
409	1858381	10:56:41



Long Short Term Memory(LSTM)

Type-4: 40(train)-20(random) seconds (Look back: 5)

Total number of points: 599

Train points: 401


Test points: 198

Look back: 5

Train Score: 49.75 RMSE

Test Score: 109.34 RMSE

395	1858211	10:55:39
396	1858291	10:55:39
397	1858224	10:55:39
398	1858166	10:55:39
399	1858262	10:55:39
400	1858235	10:55:39
401	1858243	10:55:39
402	1858102	10:55:40
403	1858390	10:56:40
404	1858325	10:56:40
405	1858260	10:56:40
406	1858353	10:56:40
407	1858381	10:56:40
408	1858357	10:56:41
409	1858381	10:56:41



Long Short Term Memory(LSTM)

Type-4: 40(train)-20(random) seconds (Look back: 10)

Total number of points: 599

Train points: 401


Test points: 198

Look back: 10

Train Score: 48.35 RMSE

Test Score: 98.65 RMSE

395	1858211	10:55:39
396	1858291	10:55:39
397	1858224	10:55:39
398	1858166	10:55:39
399	1858262	10:55:39
400	1858235	10:55:39
401	1858243	10:55:39
402	1858102	10:55:40
403	1858390	10:56:40
404	1858325	10:56:40
405	1858260	10:56:40
406	1858353	10:56:40
407	1858381	10:56:40
408	1858357	10:56:41
409	1858381	10:56:41





Next Step

- Divide the work into 3 parts:
 - PPG Data Collection
 - Time Series Prediction
 - Matching Time Series Models
- Data Collection: Need assistance to look for PPG extraction methods and
- Time Series Prediction: Using LSTM and Prophet Model
- Matching Time Series: Statistical Approach (Gaussian Mixture, Mixture of Models)



THANK YOU